


VL Cross Section



16A

- 1A - VOLUTE
- 2K - BACKPLATE
- 3A - IMPELLER
- 4A - CASE WEAR RING
- 5A - SHAFT SLEEVE
- 8A - IMPELLER CAPSCREW
- 8B - CASING BOLTING
- 10A - WASHER, IMPELLER
- 11A - BACKPLATE GASKET
- 11F - BRACKET GASKET
- 12A - KEY, IMPELLER
- 13G - SLINGER
- 14A - SHAFT SEAL
- 16A - DRAIN PLUG
- *20J - PUMP STAND
- 21A - MOTOR BRACKET
- 65A - MOTOR

*NOT PICTURED